

B. USER MANUAL

1. Change the mode

When the LED display is off (Standby Mode), press S1 to activate the LED display, and it will display the current time (Hour and Minute).

Press S1 in normal time mode to display the calendar: Month and date.

Press S1 in Calendar mode to display the second.

Press S1 in the second mode, the display returns to normal time mode.

The lighting will be on for 3 seconds after releasing the button.

2. Normal time and calendar

Adjustment

Press S2 in the Normal Time mode until you reach the Setup mode.

Press S1 to adjust, press S2 to switch between the adjustment elements.

The adjustment sequence is as follows: Hours > Minutes > Month > Date > Year (until 2049) > Format (12h or 24h).

The lighting will turn off after 5 seconds.

3. Illuminate the screen

Press S1 in standby mode, and the light will go out after 3 seconds.