



CHARACTERISTICS

This multi-display analog watch has timing functions.

CHRONOMETER

It can measure up to 59 minutes and 59 seconds.

WINDER

For normal operation, the crown must be in position 0.

The crown in position 1 allows your watch to be updated.

The crown in position 2 sets the time of your watch and indexes the timing hands.

OPERATION OF CHRONOMETER

1 - Pressing push-button A: start of the stopwatch.

2 - Pressing push-button A: stop the stopwatch.

3 - Pressure on push-button B: return to zero of the chronograph.

SETTING THE SECONDS OF THE ZERO CHRONO SECONDS

- Pull out the crown (position 2)
- Use push-piece A.