



To set the date/day, unscrew and pull the crown out to position 1, turn upwards to set the date. Turn down to set the day.

The disc indicating the day is in 2 languages: French and English; once the language of its choice has been selected, the disc keeps the display in the same language.

To set the hands, pull the crown out to position 2.

CAUTION: THIS WATCH HAS A SCREW-DOWN CROWN. IT IS IMPERATIVE TO SCREW IT BACK ON AFTER ANY HANDLING ON THE WATCH IN ORDER TO GUARANTEE ITS TIGHTNESS.