



Crown A: Adjustment of the internal rotating bi-directional bezel.

Your watch has a crown B (time setting) screwed onto the case.

To set the time of the hands, unscrew crown B.

Once unscrewed, set the time.

For the good tightness of the product, do not forget to completely screw this crown B back on.

CAUTION: THIS WATCH HAS A SCREW-DOWN CROWN. IT IS IMPERATIVE TO SCREW IT BACK ON AFTER ANY HANDLING ON THE WATCH IN ORDER TO GUARANTEE ITS TIGHTNESS.